





GENERAL

The HFD / HFP Series is designed for horizontal recessed installations in a furred down area, above a suspended ceiling or recessed in the ceiling. The HFD model is for electric heat with DX cooling. The HFP is used for heat pump applications. Installation slots are built into the cabinet to facilitate mounting the unit. Electric resistance heaters are available.



UNPACKING

Carefully unpack the unit and inspect the contents for damage. If any damage is found at the time of delivery, proper notification and claims should be made with the carrier who delivered the unit. Caution should be used when lifting the unit. **Avoid lifting by the blower wheels.** Improper handling can damage the blower wheel causing excessive vibration during operation. Check the rating plate to assure model number and voltage, plus any kits agree with what you ordered. The manufacturer should be notified within 5 days of any discrepancy or parts shortage.

LOCATION

The HFD and HFP series is designed to be installed in a recessed area (furred down) between floors, ceiling/attic area, or hung in an acoustic tile ceiling. Units may be installed in hallways, over bathrooms, or in a commercial drop-in ceiling. These units are designed for indoor use only in a horizontal position.

This unit is approved for "0" clearance from any side, front, rear or duct work. The unit must be installed in a level position to ensure proper condensation drainage. Make sure the unit is level in both directions within 1/8".

The unit incorporates installation tabs that mount to the framing and provide a 1/2" flange trim to the finished edge of a sheet rock ceiling. The access panel mounts to the cabinet and trims the installation. Before attempting installation, the following points must be considered:

Structural strength of supporting members

Clearances and provision for servicing

Power supply and wiring

Air duct connection

Drain facilities and connections

INSTALLATION GUIDE

WARNING: Due to possible damage to equipment or personal injury, installation, service and maintenance should only be performed by a trained, qualified person. Consumer service is recommended only for filter replacement.

Installation of this unit shall be made in accordance with the National Electric Code, NFPA No. 90A and 90B, and any other local codes or utilities requirements.

DUCT WORK

The duct work should be installed in accordance with the NFPA No. 90A "Installation of Air Conditioning and Ventilating Systems" and No. 90B "Residential Type Warm Air Heating and Air Conditioning Installation."

The duct work should be insulated in accordance with the applicable requirements for the particular type installation as required by HUD, FHA, VA the applicable building code, local utility or other governing body.

CONDENSATE DRAIN

The unit is supplied with 3/4" primary and auxiliary condensate drains. Both drains must be trapped outside the unit and piped in accordance with applicable building codes. Do not reduce the drain line size less than the connection size on the drain pan. Condensate should be piped to an open drain or to the outside. All drains must pitch downward away from the unit a minimum of 1/8" per foot of line to ensure proper drainage. **PVC glue is not approved or recommended on drain pan fittings. If required, use only 100% Teflon tape or sealant. All drain lines should be hand tightened.**

Caution: Do not over tighten the fitting.

Note: There are two small pieces of duct sealant putty in the bottom corners on the air discharge side of the drain pan. It is important that you seal the small air gap between the drain pan and the ductwork to prevent water from splashing out of the pan during AHU operation.

REFRIGERANT PIPING

Refrigerant pipe connections are located on the top of the unit. Refrigerant piping external to the unit shall be sized in accordance with the instructions of the manufacturer of the outdoor equipment. When the units are recessed mounted in the wall, make certain that piping connections are pressure tested prior to the wall being closed.

Manufacturer does not insulate the expansion valve, distributor tubes, or liquid lines coming from the manifold. It is the sole responsibility of the contractor to properly insulate from condensation.

(YOU MUST INSULATE THE REFRIGERANT LINES AND TXV UP TO WHERE THE PAN CATCHES ALL CONDENSATE DRIPS)

WARNING: The United States Environmental Protection Agency (EPA) has issued various regulations regarding the introduction and disposal of refrigerants in this unit. Failure to follow these regulations may harm the environment and can lead to the imposition of substantial fines. Because these regulations may vary due to the passage of new laws, we suggest that any work on this unit be done by a certified technician.

METERING DEVICE

All units are shipped with a check-flow piston installed which is designed for air conditioning or heat pump operation. If your application requires a thermal expansion valve or check expansion valve then it is necessary to remove the piston from the distributor assembly and install the proper metering device. Be sure to follow the instruction in the kit to ensure proper installation.

WIRING

Consult all schematic and pictorial wiring diagrams of this unit and the outdoor equipment to determine compatibility of the wiring connections and to determine specific requirements. All field wiring to the blower coil should be installed in accordance with the latest edition of the National Electric Code NFPA No. 70 and any local codes.

Check rating plates on the unit for rated volts, minimum circuit ampacity and maximum over current protection. Supply circuit power wiring must be 75°C (167°F) minimum copper conductors only. Copper supply wires shall be sized to the National Electric Code or local code requirements, whichever is more stringent.

INSTALLATION GUIDE

The unit is shipped wired for 230/240 Volt AC, 60 Hz, 1 Phase Operation. If the unit is to be operated at 208 VAC, 60 Hz, then follow the instruction on the indoor unit wiring diagram to change the low voltage transformer to 208 VAC operation.

Be sure the unit is properly grounded.

Class 2 low voltage control wiring should not be run in conduit with power wiring and must be separated from power wiring, unless class 1 wire of proper voltage rating is used. Low voltage control wiring should be 18 Awg, color coded (105°C minimum). For lengths longer than 100 ft., 16 Awg wire should be used. Make certain that separation of control wiring and power wiring has been maintained.

THERMOSTAT

Select a thermostat that is commonly referred to as a single stage cooling with electric heat sub base. This stat will energize the fan on a demand for heat or cool.

Install the thermostat on an inside wall away from drafts, lights, or other heat sources in a location that has good air circulation from the other rooms being controlled by the thermostat. The thermostat should be mounted 4 to 5 feet above the floor.

SEQUENCE OF OPERATION

Cooling (cooling only or heat pump with reversing valve energized in heat mode): When the thermostat calls for cooling, the blower relay is energized. The N.O. contacts will close after a time delay, and the indoor blower will operate. The circuit between R and Y is complete. Which causes the contactor on the outdoor equipment to close, and start the compressor and the outdoor fan motor.

Cooling (heat pump with reversing valve energized in cooling mode): When the thermostat calls for cooling, the circuit between R and G, and R and O is complete. Circuit R and O energizes the reversing valve to the cooling position, Circuit R and G energizes the blower relay. The N.O. contacts will close after a time delay and the indoor blower will operate. The circuit between R and Y is complete. Which causes the contactor on the outdoor equipment to close, and start the compressor and the outdoor fan motor.

Heating (electric heat only): When the thermostat calls for heat, the circuit between R and W is complete, and the heat sequencer is energized. A time delay will occur which allows the heating element(s) and the indoor blower motor to come on.

Heating (heat pump reversing valve energized in heat mode): When the thermostat calls for heat, the circuits between R and B, R and Y, and R and G are completed. Circuit R and B energize the reversing valve switching it to the position. Circuit R and G energizes the blower relay starting the blower motor.

If the indoor room temperature should continue to fall, circuit R and W2 is by the second-stage heat bulb on the thermostat. Circuit R-W2 energizes the heat sequencer. The completed circuit will energize the supplemental electric heat.

Blower Time Delay: This unit is equipped with timed on and a timed off relay. This relay delays the start and delays the stopping of the indoor fan motor to maximize the efficiency of the unit.

Defrost: When the unit starts the defrost cycle supplemental heat during defrost can be provided by connecting B on the blower coil to the defrost relay on the outdoor heat pump. This will complete the circuit between R and B in the blower coil through a set of contacts in the defrost relay in the outdoor unit. This circuit, when it is connected, will help prevent cold air from being discharged from the indoor unit during the defrost.

BLOWER

This unit is supplied with a multi-speed motor with a direct drive blower wheel which can obtain various air flows. As an option, a ECM X-13 motor is available. This motor provides variable speeds, at a constant torque, with a brush-less DC motor. (See wire diagrams on Pages 7 - 8) The unit is shipped with the blower connected for high speed. If a lower blower speed is required, disconnect all power to the unit, remove the black indoor fan motor lead from the fan relay, place an insulated cap on the black lead, remove the insulated cap from the red indoor fan motor lead, place a spade connector on the lead and connect it to the fan relay where the black lead was originally connected. Be sure to check the air flow and the temperature drop across the evaporator coil to ensure that you have sufficient air flow.

INSTALLATION GUIDE

START UP

Once all connections are completed, the unit should be started up and a check out of the completed system should be performed. Before performing any system test make sure that all grilles, registers and dampers are open and set to the correct position. Also make certain that an air filter is installed in the return air prior to running the air handler.

A performance test should be completed in accordance with the outdoor equipment manufacturer's instructions. Airflow tests should be conducted in the heating and cooling modes to ensure satisfactory operation.

MAINTENANCE

The system air filter(s) should be inspected, cleaned or replaced at least monthly. If the filter is mounted internal to unit, make sure that electrical power is disconnected before removing the access panels. Make certain that access panels are replaced and secured properly before placing the unit back in operation. This product is designed for dependable service however, periodic maintenance should be scheduled to be conducted by trained professional service personnel.

This product is designed for dependable service however, periodic maintenance should be scheduled to be conducted by trained professional service personnel. This service should be conducted at least annually, and should include testing and inspection of electrical and refrigerant components. The heat transfer surface should be cleaned. The blower motor is permanently lubricated for normal operating conditions.

⚠️ WARNINGS ⚠️

Do not store or use any corrosives or combustibles in the vicinity of this unit. All panels must be in place and properly secured before operating this equipment.

All electrical power servicing this unit must be disconnected prior to removal of any panels. Service of this unit must be accomplished by qualified trained professional personnel only.

Warranty will be voided if ANY chemical cleaning products are used on AllStyle coils. AllStyle suggests water and a soft, bristled brush for cleaning.

Conforms to UL STD 1995

THIS UNIT IS MANUFACTURED IN THE USA BY:



INSTALLATION GUIDE


Housing with Ceiling Panels

(Housing and panels are standard with ALL "H" models or can be ordered separately as a accessory kit)


CEILING PANEL/ ENCLOSURE INFORMATION										
COIL	HOUSING NO.	HOUSING DIMENSIONS			FOR MODEL	PANEL NO.	DESCRIPTION	CEILING PANEL OPENING		PANEL FRAME DIMS. (OUTSIDE)
		H	W	D				24 1/2"	40"	
30" Coil	PL-3975	11"	39 3/4"	24"	12,18,24, 30 HF	PL-3975	LOUVERED	24 1/2"	40"	28" 43 3/4"
						PS-3975	NON-LOUVERED	24 1/2"	40"	28" 43 3/4"
36" Coil	PL-4575	11"	45 3/4"	24"	36 HF	PL-4575	LOUVERED	24 1/2"	46"	28" 49 3/4"
						PS-4575	NON-LOUVERED	24 1/2"	46"	28" 49 3/4"
42" Coil	PL-5175	11"	51 3/4"	24"	37 HF	PL-5175	LOUVERED	24 1/2"	52"	28" 55 3/4"
						PS-5175	NON-LOUVERED	24 1/2"	52"	28" 55 3/4"

NOTES:

- These housings are shipped with units installed unless specified otherwise.
- Customer needs to specify on order which panel is wanted.




#PS-3975, PS-4575






#PL-3975, PL4575
(Louvers may differ from picture)

(field supplied)

ENCLOSURE INSTALLATION SUPPORT FRAMING



ENCLOSURE DIMENSIONS				
COIL	ENCLOSURE NO.	A	B	C
30" Coil	PL-3975	39 3/4"	30 5/8"	30 5/8"
36" Coil	PL-4575	45 3/4"	36 5/8"	36 5/8"
42" Coil	PL-5175	51 3/4"	42 5/8"	42 5/8"




KNOCKOUT FOR DUCTED RETURN

Requires filter grille (field supplied) Ducted return requires non-louvered panel

INSTALLATION GUIDE

ENCLOSURE CONNECTION LOCATIONS



EXPANSION VALVE KIT (HEAT PUMP AND COOLING ONLY)		
PART NUMBER	TYPE	FOR
RP31114	R-410a	1-2 TONS
RP31115	R-410a	2.5-3 TONS
RP31117	R-410a	1-2 TONS
RP31118	R-410a	2.5-3 TONS


HEAT STRIP KIT		
PART NUMBER	KW MODELS	
RP16215	3 Kw	Requires (2) 1.5 Kw Elements
RP16220	4 Kw	Requires (2) 2.0 Kw Elements
RP16224	5 Kw	Requires (2) 2.4 Kw Elements
RP16230	6 Kw	Requires (2) 3.0 Kw Elements
RP16240	8 Kw	Requires (2) 4.0 Kw Elements
RP16248	10 Kw	Requires (2) 4.8 Kw Elements

Notes:


- Expansion valve kits are approved for both heat pump or cooling only (non heat pump) applications.
- Valves are factory installed or field installed.
- Contractor friendly screw-on connections.
- Valves are external equalizing, internal bleed.
- +V For cooling only valves. Ex: HF18-30840G+V+5+H
- +VP For heat pump model valves. Ex: HF18-30840G+VP+5+H

WIRING DIAGRAM


WARNING: HAZARDOUS VOLTAGE- Ensure all power is disconnected before installing or servicing this unit. More than one disconnect device may be required to de-energize the equipment. Hazardous voltage can cause severe personal injury. Make certain all panels are in place before operating this unit.




WIRING DIAGRAM



WIRING DIAGRAM



WIRING DIAGRAM





AllStyle Coil Company, L.P. PRODUCT LIMITED WARRANTY

June 2018

Models: ASUC, Cased AS*, ASH, ASHL, Horizontal Plenum, ASQN, AB*, HF*, VL*, SL*, BL*, EL*, EF*, ADFM, ANDF

AllStyle Coil Company, L.P. offers the following standard limited warranties for products manufactured for residential applications installed in the United States. Registered evaporator coils and air handler coils installed in residential applications are given a **standard limited 5 year warranty**, with an **optional extended warranty up to 10 years, not** to exceed 11 years. Register your 10 year coil at www.allstyle.com/warranty. For any registered multi-family applications there is a **standard limited 5 year warranty** for coils, and a **limited 1 year warranty** for parts. These limited warranties extend to the original purchaser and any subsequent transferee, as long as the product remains at the site of the original installation.

Limited Warranty

AllStyle warrants to the purchaser of this product from date of manufacture should the product prove defective due to improper workmanship or materials when installed correctly, AllStyle will replace, at its option, any defective part without charge for the **part**. **Replacements Parts/Coils are warranted for the remainder of the original warranty period.**

This limited warranty does **NOT** include labor or other costs incurred for the servicing, maintenance servicing, replacing, removing, shipping or handling. The homeowner is responsible for the cost of shipping warranty replacement coils or parts from the manufacturer to the location of the covered equipment; the cost of shipping failed parts to the distributor, and for incidental costs incurred locally, including handling charges. AllStyle will not pay for any electricity or fuel costs, increases in electricity for any reason. These costs may be covered by a separate warranty provided by the selling dealer or contractor.

In establishing the starting date for the term of the **Limited 5 Year Warranty, Purchaser must register**. Register within 60 days of purchase to qualify for extended warranty. Register on-line at www.allstyle.com/warranty.

The Above Warranties are subject to the Following Conditions:

1. You must retain your bill of sale or provide other proof of purchase (Example: Proof of Installation).
2. This limited warranty applies only while the product remains at the site of the original installation, and only to products installed by licensed dealers or contractors as determined by state licensing requirements.
3. This limited warranty applies only if the product is installed and operated in accordance with AllStyle instructions and in compliance with applicable municipal codes, International building codes, and good trade practices.
4. AllStyle requires a yearly inspection and service of the equipment by a licensed technician.

AllStyle Does Not Cover:

Any costs of installation, disconnection, or dismantling the product, or parts used in connection with normal maintenance such as filters, and owner-required maintenance. Consult the instructions enclosed with the product for information regarding recommended maintenance. **AllStyle does not provide any reimbursement with this warranty, i.e. lodging, wages, any expenses, including refrigerant, etc..**

This Warranty Does Not Cover Damages Caused By:

(A) **Accident, negligence, or abuse;** (B) Operating the product in a corrosive atmosphere containing chlorine, fluorine, or any other damaging chemicals; (C) **Modification, alteration, repair or service by anyone not properly qualified to perform such service modification, alteration or repair;** (D) Improper matching or application of the product or components; (E) Failure to provide proper maintenance and service to the product according to the manufacturer's instructions; (F) **Installation or operating of the product in manner contrary to the instructions of the manufacturer;** (G) Products installed outside the United States or its territories; (H) Failure to operate due to interruption and/or inadequate electrical service; (I) Any damage caused by frozen or broken water pipes in the event of equipment failure; (J) **AllStyle is not responsible for any water damage to property. To prevent water damage, it is the installing contractors responsibility to install proper auxiliary safety pans, drain lines, and float switches to ensure proper drainage from over-flow;** (K) Damage or repair required as a result of the use of used, mixed, or recycled refrigerant; (L) **Lightning, floods, fires, winds, corrosive atmosphere or any other acts of God beyond the control of AllStyle.** **WARNING: Warranty will be voided if ANY chemical cleaning products are used on any AllStyle coils.**

How to Obtain Warranty Service:

To obtain warranty service and/or parts replacement you must notify your selling dealer or contractor of any defect within the applicable warranty period.

ALL WARRANTIES IMPLIED BY STATE LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSIVELY LIMITED TO THE DURATION OF THE LIMITED WARRANTIES SET FORTH ABOVE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. **WITH THE EXCEPTION OF ANY WARRANTIES IMPLIED BY STATE LAW AS HEREBY LIMITED, THE FOREGOING EXPRESS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, GUARANTEES, AGREEMENT, AND SIMILAR OBLIGATIONS OF MANUFACTURER OR SELLER WITH RESPECT TO THE REPAIR OR REPLACEMENT OF ANY PRODUCT OR PART.**

IN NO EVENT SHALL ALLSTYLE BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES. Some states do not allow the exclusion of incidental or consequential damages so the above limitation may not apply to you. No person, agent, distributor, dealer, or company is authorized to change, modify, or extend terms of these warranties in any manner whatsoever. The time within which an action must be commenced to **enforce** any obligation of AllStyle arising under this warranty or under any statute, or law of the United States or any states thereof, is hereby limited to one year from the date you discover or should have discovered the defect. This limitation does not apply to implied warranties arising under state law so the above provision may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Any controversy or claim arising out of or relating to this warranty, or the breach thereof, shall be settled through binding arbitration administered by the American Arbitration Association in accordance with its Commercial Arbitration Rules, and judgment on the award rendered by the arbitrator may be entered in any court having jurisdiction thereof. This is the exclusive and sole remedy of Buyer, for any breach of warranty. Pursuit of any legal remedy must occur in Harris County, Houston, Texas.

This document replaces and supersedes any and all previous warranties issued by AllStyle Coil Company, L.P.

In order to maintain the remainder of the warranty period, you must replace the failed unit with an AllStyle Coil.

©AllStyle Coil Company, L.P. June 2018

